

YGF-Tech Scan Service — API Documentation

Item	Content
Document version	v3.3
Date	2026-9-16
Service package	<code>com.eastaeon.scandecoderservice</code>
Basis	Verified line by line against the actual service source (<code>ScanDecoderService/</code>)
Sample project	<code>ScanDemo/</code> (buildable test APK + source, bilingual UI)
Replaces	The previous *Scan service interface definition (<code>Scan_service.doc</code>)*

0. Summary

The scan service exposes broadcast interfaces only — no SDK, no AIDL, no .so.

Your app —`sendBroadcast(control / settings)`—► Scan service —`sendBroadcast(result)`—► Your app

Three steps to integrate:

```
// 1) Register the result receiver (must be registered in code, NOT in AndroidManifest.xml)
IntentFilter f = new IntentFilter("com.android.server.scannerservice.broadcast");
registerReceiver(receiver, f, Context.RECEIVER_EXPORTED);

// 2) To trigger a scan from software, send one broadcast
Intent i = new Intent("com.ygf.scan_service_control_action");
i.putExtra("command", "startScanOneTimes");    // single scan
sendBroadcast(i);

// 3) Read the barcode inside the receiver
String code  = intent.getStringExtra("scannerdata");
int    codeId = intent.getIntExtra("codeId", 0);  // barcode type code
String type  = intent.getStringExtra("codeType"); // symbology name, e.g. "Code 128"
String aim   = intent.getStringExtra("aimId");    // AIM ID, e.g. "]Cm"
int    x1    = intent.getIntExtra("x1", 0);      // barcode corner coordinates
```

`ScanDemo` wraps all of this in **one file**, `ScanApi.java` — copy it into your project and you are done.

1. Service basics

Item	Value
Package	<code>com.eastaeon.scandecoderservice</code>
Identity	<code>sharedUserId=android.uid.system, persistent=true, coreApp=true</code> (system-level always-on app)
minSdk / targetSdk	19 / 23
Permissions required by your app	None. Sending and receiving broadcasts needs no permission

No configuration is required on your side. As long as the service is running on the device, the interfaces below are available.

2. Receiving scan results

2.1 The result broadcast (the only one)

After decoding a barcode the service sends **exactly one** result broadcast:

Item	Value
action	<code>com.android.server.scannerservice.broadcast</code> (default, configurable)
barcode extra	<code>scannerdata</code> (default, configurable)
Sent when	<code>barcode_send_mode</code> is <code>BROADCAST</code> or <code>FOCUS_BROADCAST</code>

2.1.1 All extras of the result broadcast

extra	Type	Description
<code>scannerdata</code>	String	Barcode content (may include prefix / suffix / end character). Key name is set by <code>key_barcode_broadcast</code>
<code>dataType</code>	String	Symbology name , e.g. <code>Code 128</code> , <code>QR Code</code> , <code>EAN-13</code> ; empty string for unknown types
<code>codeType</code>	String	Same as <code>dataType</code> (new in v3.1 — a clearer alias for customers)
<code>codeId</code>	int	Barcode type code (= ASCII code)

		of the CodeID character), e.g. 106 = Code 128, 115 = QR. Table in §2.5
aimId	String	AIM ID , e.g.]Cm ,]Qm ,]Am . Table in §2.5 ; empty string on non-SYC devices or for unknown types
x1 y1	int	Coordinate of barcode corner 1
x2 y2	int	Coordinate of barcode corner 2
x3 y3	int	Coordinate of barcode corner 3
x4 y4	int	Coordinate of barcode corner 4

About the coordinates

- The four points are the barcode corners, in the order returned by the decoder library; connect them 1→2→3→4→1 to draw the barcode outline;
- The coordinate system is that of the **image fed to the decoder: width 1280 × height 800**, origin at the **top-left**;
- To map them onto your own preview / image, just scale: **x_yours = x1 * your_width / 1280**;
- This device runs only one decode channel (1280×800), so all coordinates share the same system;
- In rare cases (result produced by another decode path) the coordinates are **0**.

Service-side implementation (**ShunfengControlService.onDecodeTwoResultCallback**):

```
Intent intent = new Intent(settings.getString("action_barcode_broadcast",
                                             "com.android.server.scannerservice.broadcast"));
intent.addFlags(Intent.FLAG_RECEIVER_FOREGROUND);
intent.putExtra(settings.getString("key_barcode_broadcast", "scannerdata"), resultString);
intent.putExtra("dataType", CodeTypeID.getCodeType(codeId));
intent.putExtra("codeId", codeId);
intent.putExtra("codeType", CodeTypeID.getCodeType(codeId));
intent.putExtra("aimId", CodeTypeID.getAimId(codeId));
intent.putExtra("x1", x1); intent.putExtra("y1", y1);
intent.putExtra("x2", x2); intent.putExtra("y2", y2);
intent.putExtra("x3", x3); intent.putExtra("y3", y3);
intent.putExtra("x4", x4); intent.putExtra("y4", y4);
sendBroadcast(intent);
```

Recommendation: keep the default action and key.

If you really need your own action name:

```
Intent i = new Intent("com.android.service_settings");
i.putExtra("action_barcode_broadcast", "com.myapp.SCAN_RESULT");
i.putExtra("key_barcode_broadcast", "barcode");
sendBroadcast(i);
```

After changing them you **must re-register your receiver with the new action/key**, otherwise you will receive nothing

(the "Apply broadcast name" button in [ScanDemo](#) demonstrates this).

⚠ Only this main broadcast carries the v3.1 fields `codelId` / `codeType` / `aimId` / coordinates.

For backward compatibility with domestic courier customers the service also fires several historical alias broadcasts

([cn.sto.pda.scan.result](#), [nlscan.*](#), [com.sunmi.*](#), ...) — those do **not** contain the new fields.

Customer apps should listen to the main broadcast above only.

2.2 Three things you must get right on the receiving side

Point	Detail
Register in code only	Custom implicit broadcasts are not delivered to receivers declared in AndroidManifest.xml since Android 8.0
Android 13+ requires the exported flag	registerReceiver(r, filter, Context.RECEIVER_EXPORTED) , otherwise it throws at runtime
Process must be alive	The result is delivered to the process that registered the receiver; a killed app receives nothing

2.3 No result? Check these three items in order

1. Is [barcode_send_mode](#) set to [FOCUS](#) / [FOCUS_OVERWRITE](#) / [CLIPBOARD](#) / [EMUKEY](#)? Those four **do not broadcast**;
2. Does your registered action/key match the service-side setting?
3. Is the scan service running? (Send [ACTION_START](#) once — see §3.1.)

2.4 Scan state broadcast (optional)

To know whether the scanner is currently scanning:

Item	Value
------	-------

action	com.eastaeon.receive_scan_control_action
extra command	onDecoderServiceReady / onDecoderConnected / onStartDecoderConnect / onStartDecoderDisconnect / onDecoderDisconnected / onDecoderConnectFailed / isScanning
extra isScanningvalue	Boolean, only for the isScanning event
extra data	String, usually empty

2.5 Barcode type: codeId / codeType / aimId table

This device uses the **SYC (Shengyuan / HS) decoder library**. The `codeId` in that library's callback is simply the

ASCII code of the CodeID character (for example the CodeID of Codabar is the character `a`, so `codeId = 97`).

The table below corresponds line by line to the "supported symbologies" list in the vendor document

解码库 Android 版本(Java)AO.pdf.

codeId	CodeID char	aimId	codeType / dataType
97	a	]Fm	Codabar
104	h	]Hm	Code 11
106	j	]Cm	Code 128 (generic ID, also covers GS1-128 / ISBT 128)
60	<	]X0	Code 32
98	b	]Am	Code 39
84	T	]L2	TLC39
105	i	]Gm	Code 93 / 93i
71	G	]X0	BC412
110	n	]X0	Plessey (UK / Anker)
100	d	]E0	EAN-13 (incl. ISBN, incl. Add-On)
68	D	]E4	EAN-8 (incl. Add-On)
121	y	]em	GS1 DataBar

123	{	]em	GS1 DataBar Limited
125	}	]em	GS1 DataBar Expanded
73	I	]C1	GS1-128
33	!	]em	GS1 Composite
81	Q	]X0	China Post (Chinese 2 of 5)
101	e	]Im	Interleaved 2 of 5
109	m	]X0	Matrix 2 of 5
89	Y	]X0	NEC 2 of 5
102	f	]Rm	Straight 2 of 5 IATA
102	f	]S0	Straight 2 of 5 Industrial (shares CodeID with IATA)
103	g	]Mm	MSI
116	t	]Bm	Telepen
99	c	]E0	UPC-A (incl. Add-On)
69	E	]E0	UPC-E
69	E	]X0	UPC-E1 (shares CodeID with UPC-E)
122	z	]zm	Aztec Code
72	H	]X0	Han Xin
119	w	]dm	Data Matrix
120	x	]Um	MaxiCode
115	s	]Qm	QR Code
115	s	]Qm	rMQR (shares CodeID with QR)
46	.	]X0	Dot Code
88	X	]X0	Grid Matrix
86	V	]06	Codablock A
113	q	]Om	Codablock F
114	r	]Lm	PDF417
82	R	]Lm	Micro PDF417

Notes on usage

Point	Detail
Shared CodeIDs	102 (f) is both Straight 2 of 5 IATA and Industrial; 69 (E) is both UPC-E and UPC-E1; 115 (s) is both QR and rMQR. <code>codeId</code> alone cannot tell them apart — the preceding row is reported by convention
Unknown symbology	A <code>codeId</code> not in the table (including Micro QR, which has no CodeID assigned in the vendor table) → <code>codeType = ""</code> , <code>aimId = ""</code> ; use the numeric <code>codeId</code> instead
Historical <code>dataType</code> bug	Before v3.1 <code>dataType</code> was always an empty string on this device (the decoder adapter only had hsm/sdc mappings). Fixed in v3.1 — it now returns the <code>codeType</code> value above
AIM ID format	Output verbatim as in the vendor "supported symbologies" list (including the <code>]</code> prefix and the modifier), e.g. <code>]Cm</code> . Character 1 is always <code>]</code> , character 3 is the modifier
Example test	"Is this a 2D code?" → <code>codeId</code> ∈ {115, 122, 119, 120, 72, 88, 114, 82, 86, 113}; "is it 1D?" → everything else

3. Controlling the scanner

3.1 Master switch (essential)

Action	Broadcast action	What the service does
Scan ON	<code>com.ygf.scandecoderservice.ShunfengControlService.ACTION_START</code>	Starts the service + sets <code>scanner_enable=true</code>
Scan OFF	<code>com.ygf.scandecoderservice.ShunfengControlService.ACTION_PAUSE</code>	Sets <code>scanner_enable=false</code> + stops the service
Restart	<code>com.eastaeon.scandecoderservice.ShunfengControlService.ACTION_RESTART</code>	Stops, then starts again after 80 ms

```
sendBroadcast(new Intent("com.ygf.scandecoderservice.ShunfengControlService.ACTION_START"));
```

Once switched off, **neither the hardware key nor software triggering produces barcodes** — the whole scan feature is disabled.

Recommended: send **ACTION_START** when your app starts or before entering the scan screen.

3.2 Software trigger (main interface)

v3.2 note: **scanner_scan_continue** (continuous scanning) and **manual_continue_enabled** (scan-while-held) are mutually exclusive; the exclusion is maintained **by the scan service itself** — enabling one automatically disables the other. The client only needs to broadcast the parameter that actually changed, **no coupling/linked commands are required**.

Item	Value
action	<code>com.ygf.scan_service_control_action</code>
extras	<code>command</code> (see below), <code>packageName</code> (caller package, recommended)

command	Meaning	Notes
<code>startScanOneTimes</code>	Single scan	Stops after one decode or timeout; most used
<code>startScan</code>	Start continuous scanning	Runs until <code>stopScan</code> is received
<code>stopScan</code>	Stop scanning	—
<code>startScanOpenLaser</code>	Laser always on (aim mode)	For hardware supporting continuous laser
<code>setScanningParameter</code>	Set low-level engine parameter	Extra <code>param(int)</code> , <code>value(int)</code>
<code>settings_changed</code>	Ask the service to reload settings	Optional after changing parameters

```
// Single scan
Intent i = new Intent("com.ygf.scan_service_control_action");
i.putExtra("command", "startScanOneTimes");
i.putExtra("packageName", getPackageName());
sendBroadcast(i);

// Continuous / stop
i.putExtra("command", "startScan");
i.putExtra("command", "stopScan");
```

The timeout of `startScanOneTimes` equals `scanner_timeout` (default 5000 ms).

If `manual_continue_enabled = true` (factory default), the single-scan timeout is forced to 60 s.

Stopping continuous scan: after `startScan` a single `stopScan` now stops it immediately (fixed on the service side —
between decodes in continuous mode there was an intermediate state where "not decoding but continuous scan still active"
and the original code dropped the stop request, so several key presses were needed to stop).

3.3 Simulating the hardware scan key (alternative)

Item	Value
action	<code>com.ygf.floatingbutton.KEY_DOWN</code>
Option A	with <code>command = startScan / stopScan / startScanOneTimes</code>
Option B	with <code>keycode = scan key code</code>

Scan key codes recognized by the service: `227, 284, 285, 286, 287, 293, 317, 318, 84`.

`keycode` is not recommended: that branch **toggles** (stops if scanning, starts if idle) and is affected by
`manual_continue_enabled / lift_scan_enabled`, so the behaviour is hard to predict.
Use the `command` form in §3.2 for precise control.

4. Settings

4.1 Which action to use

action	Parameter naming	Recommendation
<code>`com.android.service_settings`</code>	<code>scanner_xxx / sym_xxx</code>	✔ Use this one — complete parameter set
<code>com.android.scanner.service_settings</code>	<code>sound_play / vibrate / interval ...</code>	Legacy only. Its translation table is incomplete: <code>scanner_timeout</code> , <code>manual_continue_enabled</code> , <code>lift_scan_enabled</code> , <code>shortest_barcode</code> , <code>longest_barcode</code> , <code>floating_button_enabled</code> ,

		<code>reading_pane_enabled</code> cannot be passed through it
--	--	--

One broadcast may carry several parameters; the service processes them one by one.

Always include `packageName`.

4.2 Parameter reference

A. Feedback

Parameter	Type	Default	Description
<code>scanner_sound_play</code>	boolean	<code>true</code>	Beep on scan
<code>scanner_vibrate</code>	boolean	<code>false</code>	Vibrate on scan (80 ms)
<code>scan_indicatorlight_enabled</code>	boolean	<code>true</code>	Scan indicator LED (not blinking in continuous mode)
<code>scan_flash_enabled</code>	boolean	<code>true</code>	Illumination LED
<code>flashlight_mode</code>	String	<code>"150"</code>	Illumination level

The beep is played by the pre-installed sound service after receiving a

`com.eastaeon.android.PLAY_SOUND_EFFECT` broadcast. If that app is removed, `scanner_sound_play=true` stays silent.

B. Scan behaviour

Parameter	Type	Default	Description
<code>scanner_scan_continue</code>	boolean	<code>false</code>	<code>true</code> = continuous scanning; <code>false</code> = stop after one decode
<code>manual_continue_enabled</code>	boolean	<code>true</code>	Keep scanning while the hardware key is held
<code>lift_scan_enabled</code>	boolean	<code>false</code>	Scan when lifted up
<code>scanner_timeout</code>	int	<code>5000</code>	Single-scan timeout (ms), only applied if ≥1000
<code>scanner_interval</code>	int	<code>1000</code>	Continuous-scan interval (ms), only applied if ≥10

<code>boot_start</code>	boolean	<code>true</code>	Auto-start scan service on boot
<code>floating_button_enabled</code>	boolean	<code>false</code>	Floating button

C. Result handling

Parameter	Type	Default	Description
<code>barcode_send_mode</code>	String	<code>FOCUS_BROADCAST</code>	How the result is delivered, see §4.3
<code>scanner_prefix</code>	String	<code>""</code>	Barcode prefix
<code>scanner_suffix</code>	String	<code>""</code>	Barcode suffix
<code>scanner_endchar</code>	String	<code>ENTER</code>	End character, see §4.4
<code>filter_prefix_suffix_blank</code>	boolean	<code>false</code>	Trim leading/trailing blanks
<code>action_barcode_broadcast</code>	String	<code>com.android.server.scannerservice.broadcast</code>	Result broadcast action
<code>key_barcode_broadcast</code>	String	<code>scannerdata</code>	Result broadcast extra key
<code>barcode_chinese_coding</code>	String	<code>""</code>	Encoding for Chinese codes, e.g. <code>"GBK"</code>
<code>shortest_barcode</code>	int	—	Minimum barcode length (1–9999)
<code>longest_barcode</code>	int	—	Maximum barcode length (1–9999)
<code>result_prefix_control</code>	int	—	Drop the first N characters of the result
<code>result_output_control</code>	int	—	Drop the last M characters of the result

<code>divider_settings</code>	boolean	—	Auto-remove a trailing <code>_</code> / <code>-</code>
-------------------------------	---------	---	--

D. Saving scan images

Parameter	Type	Default	Description
<code>save_pic_enabled</code>	boolean	<code>false</code>	Save the raw scan image
<code>scan_save_pic_days</code>	int	3	Retention in days (1–30)

E. Symbology switches (complete list, new in v3.1)

Naming rule: `sym_<symbology>_<suffix>`, sent via the ``com.android.service_settings`` broadcast:

Parameter	Type	Description
<code>sym_<code>_enable</code>	boolean	Enable/disable one symbology, e.g. <code>sym_qr_enable = false</code>
<code>sym_<code>_min</code>	int	Minimum length for that symbology
<code>sym_<code>_max</code>	int	Maximum length for that symbology
<code>sym_all_code_enable</code>	boolean	Enable (<code>true</code>) / disable (<code>false</code>) all symbologies at once
<code>sym_reset_all_code_enable</code>	boolean	Restore all symbology defaults + reset business defaults (send mode, end character, ...) + <code>scanner_enable=true</code>

⚠ **Types matter:** `_enable` must be `putExtra(String, boolean)`, `_min` / `_max` must be `putExtra(String, int)`.

A string value is treated as the default, which looks like "the broadcast was sent but had no effect".

The 35 main switches (all symbologies supported on this device)

#	Parameter	Symbology		#	Parameter	Symbology
1	<code>sym_aztec_enable</code>	Aztec Code		19	<code>sym_upca_enable</code>	UPC-A
2	<code>sym_codabar_enable</code>	Codabar		20	<code>sym_upce0_enable</code>	UPC-E0/UPC-E

3	<code>sym_code11_enable</code>	Code 11		21	<code>sym_upce1_upce1_enable</code>	UPC-E1 ⚠ doubled suffix here
4	<code>sym_code128_enable</code>	Code 128		22	<code>sym_iata25_enable</code>	Straight 2 of 5 IATA
5	<code>sym_code39_enable</code>	Code 39		23	<code>sym_codablock_a_enable</code>	Codablock A
6	<code>sym_code93_enable</code>	Code 93		24	<code>sym_codablock_f_enable</code>	Codablock F
7	<code>sym_datamatrix_enable</code>	Data Matrix		25	<code>sym_msi_enable</code>	MSI
8	<code>sym_ean8_enable</code>	EAN-8		26	<code>sym_tlcode39_enable</code>	TLC39
9	<code>sym_ean13_enable</code>	EAN-13		27	<code>sym_trioptic_enable</code>	Trioptic Code 39
10	<code>sym_int25_enable</code>	Interleaved 2 of 5		28	<code>sym_strt25_enable</code>	Straight 2 of 5 Industrial
11	<code>sym_maxicode_enable</code>	MaxiCode		29	<code>sym_matrix25_enable</code>	Matrix 2 of 5
12	<code>sym_micropdf_enable</code>	Micro PDF417		30	<code>sym_nec25_enable</code>	NEC 2 of 5
13	<code>sym_pdf417_enable</code>	PDF417		31	<code>sym_telepen_enable</code>	Telepen
14	<code>sym_qr_enable</code>	QR Code		32	<code>sym_usps4cb_enable</code>	USPS 4 State
15	<code>sym_rss_rss_enable</code>	GS1 DataBar		33	<code>sym_gs1_128_enable</code>	GS1-128
16	<code>sym_rss_rsl_enable</code>	GS1 DataBar Limited		34	<code>sym_hanxin_enable</code>	Han Xin
17	<code>sym_rss_rse_enable</code>	GS1 DataBar Expanded		35	<code>sym_hk25_enable</code>	China Post (HK25)
18	<code>sym_gridmatrix_enable</code>	Grid Matrix				

There are also several fine-grained switches (normally no need to touch). ⚠ Note: fine-grained keys do **NOT** all follow the `sym*_enable` boolean rule —

the inverse switches are **String-typed without the `\_enable` suffix** (`sym_c128_inverse`,
`sym_code93_inverse`, `sym_int25_inverse`, `sym_pdf417_inverse`,

values "0"/"1"/"2", send with `--es`), and rectangular DataMatrix is a **boolean without suffix** (`sym_datamatrix_rectangle`, send with `--ez`).

Boolean fine-grained keys include: `sym_chinapost_enable`, `sym_koreapost_enable`, `sym_code32_enable`, `sym_code49_enable`, `sym_composite_enable`, `sym_composite_upc_enable`, `sym_isbt_enable`, `sym_auspost_bar_output_enable`, `sym_postnet_check_transmit_enable`, `sym_code39_check_enable`, `sym_code39_check_transmit_enable`, `sym_code39_fullascii_enable`, `sym_ean13_2_digit_addenda_enable`, ... (a mistyped key is silently ignored by the service — no error, no effect).

Examples

```
// Decode QR + Code 128 only, everything else off
Intent i = new Intent("com.android.service_settings");
i.putExtra("packageName", getPackageName());
i.putExtra("sym_all_code_enable", false);           // disable all first
i.putExtra("sym_qr_enable", true);                 // then enable QR
i.putExtra("sym_code128_enable", true);            // then enable Code 128
i.putExtra("sym_qr_min", 1);                       // QR min length
i.putExtra("sym_qr_max", 500);                     // QR max length
sendBroadcast(i);

// Restore factory defaults (all symbologies + business parameters)
Intent r = new Intent("com.android.service_settings");
r.putExtra("packageName", getPackageName());
r.putExtra("sym_reset_all_code_enable", true);
sendBroadcast(r);
```

Nothing else is needed afterwards: the service detects the symbology change and reloads the decoder engine itself.

F. Auxiliary

Parameter	Type	Description
<code>packageName</code>	String	Caller package name; recommended on every request

The `pda_*` family (disable keys, hide status bar, silent APK install, ...) is device-customization level and requires system privileges. Regular apps cannot use them; not covered here.

4.3 `barcode_send_mode` values

Value	Where the result goes	Broadcast?
-------	-----------------------	------------

FOCUS_BROADCAST	Focused input field and broadcast	☑ factory default
BROADCAST	Broadcast only	☑ recommended for your app
FOCUS	Focused input field only (append)	✗
FOCUS_OVERWRITE	Focused input field, overwrite	✗
CLIPBOARD	System clipboard	✗
EMUKEY	Typed as keyboard input, character by character	✗

⚠ Unless the mode is **BROADCAST** / **FOCUS_BROADCAST**, your app receives **no result broadcast at all**.

If your app needs the data, **set `BROADCAST`**.

4.4 scanner_endchar values

Value	Appended to the result
ENTER	\n (factory default)
NONE	nothing
TAB	\t
SPACE	a space

Case sensitive — must be upper case.

4.5 When do settings take effect?

- Parameters are written to shared preferences and take effect on the next scan **immediately**;
- Engine-related parameters (symbology switches, timeout, interval, image saving)

trigger an automatic reload inside the service — no extra action needed;

- To force a full reload, send:

```
Intent i = new Intent("com.ygf.scan_service_control_action");
i.putExtra("command", "settings_changed");
sendBroadcast(i);
```

4.6 Complete example (several parameters in one broadcast)

```
Intent i = new Intent("com.android.service_settings");
i.putExtra("packageName",      getPackageName());
i.putExtra("scanner_sound_play", true);           // beep
i.putExtra("scanner_vibrate",  true);             // vibrate
i.putExtra("scanner_scan_continue", false);       // no continuous scan
```

```

i.putExtra("barcode_send_mode",      "BROADCAST"); // results via broadcast only
i.putExtra("scanner_endchar",        "ENTER");      // append newline
i.putExtra("scanner_timeout",        5000);          // ms, >= 1000
i.putExtra("scanner_interval",       1000);          // ms, >= 10
i.putExtra("scanner_prefix",         "");
i.putExtra("scanner_suffix",         "");
i.putExtra("sym_qr_enable",          true);           // enable the common symbologies only
i.putExtra("sym_code128_enable",     true);
i.putExtra("sym_code39_enable",     true);
sendBroadcast(i);

```

5. Other broadcast interfaces (optional)

5.1 Read the PDA serial number

```

sendBroadcast(new Intent("com.android.receive_get_pda_sn"));

// Result: action = com.android.receive_pda_sn, extra: pda_sn (register a receiver in code)

```

5.2 Temporarily mute the scan beep (global)

```

Intent i = new Intent("com.eastaeon.sdk.CLOSE_SCAN_SOUND");
i.putExtra("EXTRA_CLOSE_CTRL", true);    // true = mute, false = unmute
sendBroadcast(i);

```

Unlike `scanner_sound_play`, this is a global mute with higher priority.

6. Quick reference

I want to...	Send
Turn scanning on	<code>...ShunfengControlService.ACTION_START</code>
Turn scanning off	<code>...ShunfengControlService.ACTION_PAUSE</code>
Scan once	<code>com.ygf.scan_service_control_action + command=startScanOneTimes</code>
Start continuous scan	<code>com.ygf.scan_service_control_action + command=startScan</code>
Stop	<code>com.ygf.scan_service_control_action + command=stopScan</code>
Receive results	register <code>com.android.server.scannerservice.broadcast</code> in code, read <code>scannerdata</code>
Get the barcode type	same broadcast: <code>codeId(int)</code> / <code>codeType(String)</code> /

	<code>aimId(String)</code> , see §2.5
Get the barcode position	same broadcast: <code>x1,y1 ~ x4,y4</code> , coordinate system 1280×800
Beep on/off	<code>com.android.service_settings + scanner_sound_play</code>
Vibrate on/off	<code>com.android.service_settings + scanner_vibrate</code>
Continuous mode	<code>com.android.service_settings + scanner_scan_continue</code>
Change send mode	<code>com.android.service_settings + barcode_send_mode</code>
Change end character	<code>com.android.service_settings + scanner_endchar</code>
Change result action/key	<code>com.android.service_settings + action_barcode_broadcast / key_barcode_broadcast</code>
Enable/disable a symbology	<code>com.android.service_settings + sym_<symbology>_enable</code> (list in §4.2-E)
Allow only specific symbologies	<code>sym_all_code_enable=false</code> then <code>sym_xxx_enable=true</code> one by one
Restore symbology defaults	<code>com.android.service_settings + sym_reset_all_code_enable=true</code>

7. FAQ

Q1. The hardware key decodes, but my app receives nothing.

A: Check `barcode_send_mode`. Only `BROADCAST` / `FOCUS_BROADCAST` broadcast. If it was changed to `FOCUS` / `CLIPBOARD`, nothing is sent — just set `barcode_send_mode=BROADCAST`.

Q2. `startScan` does nothing.

A: ① Is the master switch on (`ACTION_START`)? ② Is the screen on and unlocked? (No response while the screen is off or locked.) ③ Is the camera occupied by another app?

Q3. The result has an extra (or missing) newline.

A: Controlled by `scanner_endchar`, default `ENTER` (`\n`). Set it to `NONE` to remove.

Q4. `scanner\_timeout` has no effect.

A: ① The value must be ≥ 1000 . ② If you use the legacy action

`com.android.scanner.service_settings`, this parameter is

not forwarded — use `com.android.service_settings`. ③ If `manual_continue_enabled=true` (default), the single-scan

timeout is forced to 60 s.

Q5. After changing `action_barcode_broadcast` I no longer receive results.

A: You must re-register your receiver with the new action/key.

Q6. `dataType` / `aimId` are empty strings.

A: ① The `codeId` of that result is not in the §2.5 table (for example Micro QR, which has no CodeID in the vendor

table); ② `aimId` is currently only supported on SYC (Shengyuan) decoder devices — other devices return "".

In that case use the numeric `codeId` instead.

Q7. What is the relationship between `codeId` and `dataType`?

A: `codeId` is the **raw type code from the decoder library** (ASCII code of the CodeID character) — stable and

language-independent, so it is the recommended value for program logic; `codeType` / `dataType` is the **readable name**

of the same symbology, better for logs or UI. They map one-to-one; see §2.5.

Q8. The coordinates `x1..y4` are all 0.

A: ① In rare cases the result comes from a non-callback decode path that carries no coordinates;

② coordinates are returned as 0 when the barcode was recognized but corner information is unavailable;

③ make sure the firmware on the device actually contains the v3.1 changes.

Q9. A symbology switch broadcast has no effect.

A: ① Check the extra type: `_enable` must be boolean, `_min/_max` must be int;

② make sure you use `com.android.service_settings` (the legacy action does not forward `sym_*`);

③ the easiest way to verify is `sym_all_code_enable=false` followed by enabling one specific symbology.

Q10. A broadcast seems to have no effect — how to isolate the problem?

A: Send the very same broadcast from a shell first to separate "interface problem" from "app problem":

```
adb logcat -s ShunFengReceiver ServiceReceiver ScanService ShunfengControlService  
SYCDecoderServiceHelper  
  
adb shell am broadcast -a com.ygf.scan_service_control_action --es command startScanOneTimes  
adb shell am broadcast -a com.ygf.scandecoderservice.ShunfengControlService.ACTION_START  
adb shell am broadcast -a com.android.service_settings --es barcode_send_mode BROADCAST  
adb shell am broadcast -a com.android.service_settings --ez sym_qr_enable true
```

If the shell command produces a barcode, device and interface are fine and the problem is in your app; if not,
the problem is on the device/firmware side.